Maintenance & Service Guide

Maintenance & Service Guide v3.1

Daily checklist
1. Hull and propeller inspection
2. Battery and connector check
3. Antenna and gimbal check

Wear parts replacement interval
Propeller ..... 6 months
Sealing ring ..... 12 months
Battery pack ..... 24 months